



Pilot operated 5-port ISO valve DIN terminal box

PV5G-6/8 Series


Parts Expanded View




●DIN terminal box

Part model No.	Parts diagram	No.
PVG-DIN-TRM-BOX		1


●DIN terminal box gasket

Part model No.	Parts diagram	No.
PV5G-DIN-TRM-BOX-GASKET		2

●Base gasket

Model No.	Part model No.	Parts diagram	No.
PV5G-6	PV5G-6-BASE-GASKET		3
PV5G-8	PV5G-8-BASE-GASKET		

MEMO





Pilot operated 5-port ISO valve DIN terminal box
Individual wiring manifold

GMF1, GMF2 Series

GMF1, GMF2 Series

●Mixed block

Part model No.	Parts diagram	Qty.
U side: 2 types D side: 1 type		1
U side: 1 type D side: 2 types		


●Manifold block

Model No.	Part model No.	Parts diagram	Qty.
Left and right sides for piping	GMF1	GMFB1-02T	1
		GMFB1-03T	
	GMF2	GMFB2-03T	
		GMFB2-04T	
Rear side for piping	GMF1	GMFB1-02Z	1
		GMFB1-03Z	
	GMF2	GMFB2-03Z	
		GMFB2-04Z	



●Foot

Model No.	Part model No.	Parts diagram	Qty.
U side	GMF1	GFB1-03U	1
		GFB1-04U	
	GMF2	GFB2-04U	
		GFB2-06U	
D side	GMF1	GFB1-03D	1
		GFB1-04D	
	GMF2	GFB2-04D	
		GFB2-06D	


●Foot set (D and U set)

Model No.	Part model No.	Parts diagram	Qty.
GMF1	GFB1-03T		1
	GFB1-04T		
GMF2	GFB2-04T		1
	GFB2-06T		


●Discrete sub-plate

Model No.	Part model No.	Parts diagram	Qty.
PV5G-6	CB1-A02		1
	CB1-A03		
PV5G-8	CB2-A03		1
	CB2-A04		
	CB2-A06		


●Masking plate

Model No.	Part model No.	Parts diagram	Qty.
GMF1	CM1-00		1
GMF2	CM2-00		


●Base gasket

Model No.	Part model No.	Parts diagram	Qty.
GMF1	PV5G-6-BASE-GASKET		1
GMF2	PV5G-8-BASE-GASKET		

●Flow path cutoff plate

Model No.	Part model No.	Parts diagram	Qty.
GMF1	GM1-01		1
GMF2	GM2-01		

●Mounting screw

Model No.	Part model No.	Parts diagram	Qty.
GMF1	GMF1-M5X35		4
	GMF1-M5X65		
	GMF1-M5X75		
	GMF1-M5X95		
	GMF1-M5X105		
	GMF1-M5X115		
	GMF1-M5X145		
GMF2	GMF2-M6X45		4
	GMF2-M6X85		
	GMF2-M6X100		
	GMF2-M6X105		
	GMF2-M6X125		
	GMF2-M6X140		
	GMF2-M6X145		
	GMF2-M6X160		
	GMF2-M6X200		

●Metal plug (hexagon socket head cap plug)

Part model No.	Parts diagram	Qty.
PV5-PLUG-R1/4		1
PV5-PLUG-R3/8		
PV5-PLUG-R1/2		
PV5-PLUG-R3/4		

●Tie rod

Model No.	Part model No.	Parts diagram	Qty.
GMF1	GMF1-TR-V1		2
	GMF1-TR-V2		
	GMF1-TR-V3		
	GMF1-TR-V4		
	GMF1-TR-V5		
	GMF1-TR-V6		
	GMF1-TR-V7		
	GMF1-TR-V8		
	GMF1-TR-V9		
	GMF1-TR-V10		
GMF2	GMF2-TR-V1		2
	GMF2-TR-V2		
	GMF2-TR-V3		
	GMF2-TR-V4		
	GMF2-TR-V5		
	GMF2-TR-V6		
	GMF2-TR-V7		
	GMF2-TR-V8		
	GMF2-TR-V9		
	GMF2-TR-V10		


●Mounting screw (for fastening between foot and tie rod)

Model No.	Part model No.	Parts diagram	Qty.
GMF1	GMF1-M6X25		4
GMF2	GMF2-M8X30		


●Tie rod for station expansion

Model No.	Part model No.	Parts diagram	Qty.
GMF1	GMF1-TR-VZ		2
GMF2	GMF2-TR-VZ		

●Spacer regulator gage (common to GMF1/GMF2)

Part model No.	Parts diagram	Qty.
CMF1-SR-05-GAUGE		1

●Diaphragm assembly

Model No.	Part model No.	Parts diagram	Qty.
GMF1	CMF1-SR-DIAPHRAGM-ASSY		1
GMF2	CMF2-SR-DIAPHRAGM-ASSY		