

(M)W4G*2 Series

3, 5-port pilot operated valve, plug-in block manifold

Cartridge push-in fitting and related parts Discrete


Cartridge push-in fitting and related parts (for output port 4 (A), 2 (B))

	Fitting	Part model No.	Parts diagram	Qty.
ø4	Push-in	4G2-JOINT-C4	Cartridge push-in fitting Plug Cartridge	
	Push-in	4G2-JOINT-C6		
ø6	Push-in short elbow	4G2-JOINT-CL6		
	Push-in long elbow	4G2-JOINT-CLL6		1
	Push-in	4G2-JOINT-C8		•
ø8	Push-in short elbow	4G2-JOINT-CL8	Fitting stopper	
	Push-in long elbow	4G2-JOINT-CLL8		
F	Plug cartridge	4G2-JOINT-CPG		

Cartridge push-in fitting and related parts (for supply and exhaust block 1 (P), 3/5 (R), 12/14 (PA), 82/84 (PR))

	Fitting	Part model No.	Parts diagram	Qty.
Supply a	and exhaust block fo	r 1(P), 3/5(R)	A 24	
	Push-in	N4G2-Q-JOINT-8		
ø8	Push-in short elbow	N4G2-Q-JOINT-8L	N4G2-Q-*	
	Push-in long elbow	N4G2-Q-JOINT-8LL	N4G2-QK-*	
	Push-in	N4G2-Q-JOINT-10		
ø10	Push-in short elbow	N4G2-Q-JOINT-10L		1
	Push-in long elbow	N4G2-Q-JOINT-10LL	N4G2-QK-*	
	Plug cartridge	N4G2-Q-JOINT-PG	N4G2-Q- *L	_
Supply a	and exhaust block fo	r 12/14 (PA), 82/84 (RR)		
ø6	Push-in	N4G2-QK-JOINT-6		
y U	Push-in short elbow	N4G2-QK-JOINT-6L	N4G2-Q-*LL	

Adaptor related kit



Fitting adapter kit

NC/NO	Port s	size	Part model No.	Parts diagram	No.	Qty.	
		ø4	4G2-JNT-ADAPTOR-KIT-C4-□				
Blank	Push-in	ø6	4G2-JNT-ADAPTOR-KIT-C6-□				
		ø8	4G2-JNT-ADAPTOR-KIT-C8-□				
	Push-in	ø4	4G2-JNT-ADAPTOR-KIT-C4NC-□		4	2	
NC		ø6	4G2-JNT-ADAPTOR-KIT-C6NC-□		6	1	
		ø8	4G2-JNT-ADAPTOR-KIT-C8NC-□		6	1	
			ø4	4G2-JNT-ADAPTOR-KIT-C4NO-□			
NO	Push-in	ø6	4G2-JNT-ADAPTOR-KIT-C6NO-□				
		ø8	4G2-JNT-ADAPTOR-KIT-C8NO-□				

^{☐:} Option blank; none F; port A/B filter integrated

Female thread adapter kit


NC/NO	Port size	Part model No.	Parts diagram	No.	Qty.
Blank	ø6	4G2-FML-ADAPTOR-KIT-06-□			
NC	ø6	4G2-FML-ADAPTOR-KIT-06NC-□		9 9	1
NO	ø6	4G2-FML-ADAPTOR-KIT-06NO-□		•	'

^{☐:} Option blank; none F; port A/B filter integrated

Manifold related part


Discrete sub-plate related parts


●Cable clamp (with gasket)



Part model No.	Parts diagram
W4G-BMS-038GP	

Manifold related parts





Masking plate kit

 			
Part model No.	Parts diagram	No.	Qty.
W4G2-MP		0	1 1 2 1

Part model No.	Parts diagram	No.
4G2-GASKET		0

Gasket with exhaust check valve

Part model No.	Parts diagram	No.			
4G2-CHECK-VALVE		•			

Part model No.	Parts diagram	No.	Qty.
4G2-PR		6	2

●PR plug

Part model No.	Parts diagram	No.	Qty.
4G2-PR-PLUG		3	1

●PR check valve kit

Gasket

●Mounting screw					
Part model No.	Parts diagram	No.	Qty.		
4G2-SET-SCREW		6	10		

●Cable clamp (for wiring block T10)

Cable stamp (i.e. immig breek i i.e)				
Part model No.	Parts diagram			
N4G2-SCL-18A				
N4G2-SCL-18B				

■Tie rod

Part model No.		Parts diagram	Qty.
For 1-station valve block	W4G2-TR-V1		
For supply and exhaust block	W4G2-TR-Q		2
For partition block	W4G2-TR-S		2
For I/O block	W4G2-TR-M	-	

■Tag holder

Part model No.	Parts diagram	Qty.
N4G2-TAG-HOLDER		2

●Tag plate

Tag plate				
Model No.	Length	Part model No.	Parts diagram	
	200 mm	N4G2-TAG-PLATE-A-200		
W4GA2	300 mm	N4G2-TAG-PLATE-A-300		
	400 mm	N4G2-TAG-PLATE-A-400		
	200 mm	N4G2-TAG-PLATE-B-200		
W4GB2 W4GZ2	300 mm	N4G2-TAG-PLATE-B-300		
	400 mm	N4G2-TAG-PLATE-B-400		

●DIN rail

Part model No.	Parts diagram
N4G-BAA [length]	

●DIN rail mounting bracket

Part model No.	Parts diagram	Qty.
W4G2-D		Mounting bracket: 2 Mounting screw: 4

One set serves as one manifold set.

●Waterproof cap (for I/O block)

Part model No.	Parts diagram
W4G2-XSZ-11	

For power supply connector protection

●Waterproof plug (for I/O block)

Part model No.	Parts diagram	
W4G2-XSZ-12		

For protecting the unused signal connector

●Cable with multi-connector (wiring method T20)

Cable length	Part model No.	Parts diagram
1 m	W4G-RMC-1	₽₽ → -
3 m	W4G-RMC-3	
5 m	W4G-RMC-5	

•Multi-connector only (wiring method T20)

	, ,	,
Applicable cable diameter	Part model No.	Parts diagram
ø8	W4G-RM21WTP-8	
ø10	W4G-RM21WTP-10	
ø12	W4G-RM21WTP-12	

● Cable with D-sub-connector (wiring method T30)

Cable with D-sub-connector (wiring method 130)			
User interface	Cable length	Part model No.	Parts diagram
	1m	N4T-CABLE-D00-1	
Cut only	3m	N4T-CABLE-D00-3	
	5m	N4T-CABLE-D00-5	
With round terminal for M3.5 screw	1m	N4T-CABLE-D01-1	
	3m	N4T-CABLE-D01-3	
	5m	N4T-CABLE-D01-5	